



LIVING ROOM DIY PROJECT

PRIMER PREPARES POROUS SURFACES FOR PAINTING

SUPPLYLIST

- Primer: KILZ 2® All-Purpose
- Paint: KILZ Complete Coat®
 - Walls – Prussian Blue RD100-02
 - Fireplace – Swiss Coffee LJ240A
- 3/8"-1/2" Nap Paint Roller
- Paint Brush
- Drop Cloth
- Tape
- Damp Cloth
- Can Key
- Stir Stick



WALLS

- 1** Wipe down walls with a damp cloth to ensure they are clean and free of dust. Allow to dry.



- 2** Tape around the fireplace, baseboards and moldings with painter's tape to ensure you don't get primer or paint where you don't want it!



- 3** Next, apply 1 coat of **KILZ 2® All-Purpose** (stirring thoroughly before and occasionally during use) to the walls and allow to dry. Apply primer using a brush first to "cut in" around the edges, then use a roller to fill in.



- 4** Once primer is dry, apply **KILZ Complete Coat®** in Prussian Blue using the same application method as the primer (using a brush first to cut in around the edges 4 to 6 feet at a time, then use a roller to fill in those sections before moving along).



- 5** Remove the tape before the paint is fully dry.

Always remember to refer to our website kilz.com or product back labels for additional information on which primer is right for your project and detailed instructions on how to apply our products.